

BAZOONGI KIDS[™]

"Kids Cottage" Item #11125/11126

"Kids Cottage" is our best selling Bazoongi® Kids Play Structure. It is made of industry approved spun-bonded material with bright and rich colors. Our innovative design allows easy assembly, and the revolutionary G3 poles add strength to the structure.

Enjoy your Bazoongi® Kids Cottage and be sure to contact us for any further information.

PLEASE READ ALL OF THE DIRECTIONS PRIOR TO ASSEMBLY. DO NOT APPLY EXCESS FORCE TO THE POLES DURING ASSEMBLY. ASSEMBLE WITH ADULT SUPERVISION ONLY.


Parts list

2 - Long Blue Poles 1 - Long White Pole 2 - Short Blue Poles 4 - Short White Poles

4 - Red Poles 1 - Cottage Tent Body 2 - Yellow Poles 1- Floor Sheet

Detachables: please refer to the graphic on page 2.

1. Assemble the Cottage Frame completely BEFORE placing the Cottage Body onto the frame.
2. Straighten all of the segments of the G3 poles with shock cords.
3. Using the 2 Long Blue Poles and the 2 Short Blue Poles, Press the poles into the corner fittings to make a rectangular base (Fig. A).
4. Press the 4 Red Poles into the Upright slots of the corner connectors on the rectangular base (Fig. B).
5. Attach the Yellow Poles to the top of the Red Poles (Fig. C).
6. Insert the 4 Short White Poles into the connectors of the Yellow Poles (Fig. D).
7. Attach the Long White Pole to the 4 Short White Poles using the attached connectors (Fig. E).
8. Slide the material of the Cottage Body OVER the assembled frame.
9. Flip the Cottage onto its side and then slide the bottom corners of the frame into the pockets on the cottage body.
10. Attach the floor sheet below the Cottage by attaching the velcro sewn onto the cottage body and the floor sheet.



Now, you can attach all colorful detachable decorations onto tent body by attaching the Velcro sewn onto the tent body and the detachables themselves.

Care & Safety Instructions

- . This item is for indoor use only. Direct Sunlight can degrade the material.
- . Do not Wash! Clean only with damp cloth! . Never Store Wet. Store in a cool dry location.
- . Keep this tent away from heat sources or open flame.

Warning! "Keep All Flame And Heat Sources Away From This Tent Fabric. This Tent Is Made With Fabric That Meets ASTM F963 Specifications For Flame Resistance. It Is Not Fire Proof. The Fabric Will Burn If Left In Continuous Contact With Any Flame Source. The application of any foreign substance to the tent fabric may render the flame resistant properties ineffective."

Detachables for #11125

